Mandis shop

TNR3

Original		Replacement	
ON	On	Power	
OFF	Off	SHIFT + Power	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SLEEP	Sleep	PROG SLEEP	Sleep
MEM	Mem	REC MODE	Rec
DEL	Del	CLEAR EXIT	Exit
FM	FM	HOME SMART	Smart
AM	AM	APP MEDIA	Media

Original		Replacement	
PRESET	Preset Up		Up
PRESET	Preset Down		Down
TUNE	Tune >		Right
TUNE	< Tune		Left
ENTER	Enter	OK	Ok
BLEND	Blend	SETTINGS OPT	Options
FM MUTE	FM Mute	MUTE	Mute
DIMMER	Dimmer	SEARCH TV/R	TV/R

https://mandos-a-distancia.es/en/NAD/1063311-88100-replacement-remote-control-for-NAD-TNR3.html