Original	Replacement
Power	Power
Red	Red
Green / I-II	Green
Green / I-II	Dual
Yellow	Yellow
Blue	Blue
[i+]	Info
[⇕]	Eject
[⏸]	Pause
[?]	Smart
Smart Audio	Shift + Dual
Radio	TV/R
Smart Picture	Format
Menu	Menu
[≡]	Text
Up	Up
Left	Left

Original	Replacement
Right	Right
Down	Down
Vol +	Vol +
Vol -	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement	Original	Replacement
Sl eep	Sl eep		
Exi t	Exi t		