Mandis shop

Promethean MXBE

Original		Replacement	
ON/STAND-BY	On / Stnad-By		Power
AUTO SET	AUTO SET	HOME SMART	Smart
COMPUTER 1	COMPUTER 1	1	1
COMPUTER 2	COMPUTER 2	2	2
HDMI	HDMI	3	3
VIDEO	VIDEO	4	4
S-VIDEO	S-VIDEO	5	5
COMPONENT	COMPONENT	6	6
	UP		Up
	LEFT		Left
SELECT	SELECT	OK	Ok
	RIGHT		Right
	DOWN		Down
MENU	MENU	TOP MENU MENU	Menu
SCREEN	SCREEN	E-MANUAL D.MENU	D. Menu
KEYSTONE	KEYSTONE	SETTINGS OPT	Options
INFO.	INFO.	DISPLAY INFO	Info

Original		Replacement	
FREEZE	FREEZE		Pause
NO SHOW	NO SHOW		Stop
P-TIMER	P-TIMER	TIMER AV	AV
LAMP	LAMP	SHIFT +	Shift + Power
D.ZOOM +	D. ZOOM +	CH +	Ch +
D.ZOOM -	D. ZOOM -	CH -	Ch -
VOLUME+	VOLUME+	VOL +	Vol +
VOLUME-	VOLUME-	VOL -	Vol -
MUTE	MUTE	MUTE	Mute
IMAGE	IMAGE	ECO 3D	3D
ASPECT	ASPECT	PICTURE FORMAT	Format
	AUTO PC	APP MEDIA	Media

https://mandos-a-distancia.es/en/Promethean/1063302-65353-replacement-remote-control-for-Promethean-MXBE.html