Mandis shop

# Samsung AH5902710A

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| MUTE | Mute | MUTE | Mute |
| AUX | AUX | APP MEDIA | Media |
| D.IN | D.IN | HOME SMART | Smart |
| WOOFER LEVEL | Woofer Level | + CH | Ch + |
| WOOFER LEVEL | Woofer Level | CH − | Ch - |
| + VOL | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| ▶II | Play | PLAY MODE ▶ | Play |
| ▶II | Pause | II | Pause |
| ▶▶I | >>I | ▶▶I | >>I |
| I◀◀ | I<< | I◀◀ | I<< |
| TV SOUND CONNECT | Tv Sound | SEARCH TV/R | TV/R |
| Bluetooth | Bluetooth | SETTINGS OPT | Options |
| SOUND EFFECT | Sound Effect | SOUND DUAL | Dual |
| AUTO POWER | Auto Power | PROG SLEEP | Sleep |
| Bluetooth POWER | Bluetooth | SHIFT + | Shift + Power |

| Original | | Replacement | |
|---|---|---|---|
| USB | USB | TIMER AV | AV |

Power

https://mandos-a-distancia.es/en/Samsung/1056314-66021-replacement-remote-control-for-Samsung-TM1110-AH59-02710A.html