Mandis shop

Samsung DJ 96-00114Z

Original		Replacement	
Power	Power		Power
Recharging	Recharging	RETURN BACK	Back
Auto	Auto	1	1
Spot	Spot	2	2
Max	Max	3	3
	Up		Up
	Right		Right
	Left		Left
Start/ Stop	Start/Stop	OK	Ok
Manual	Manual	4	4
Turbo/Silence	Turbo/Silence	5	5
Dust Sensor	Dust Sensor	6	6
Schedule	Schedule	7	7
Clock	Clock	8	8
Sound/Remote	Sound/Remote	9	9

Original	Replacement