Mandis shop

Thomson CS520

Original	Replacement	Original	Replacement
On/Eco	Power	Repeat/RDS	Text
Vol+	Vol +	PTY	Guide
Vol-	Vol -	Sleep	Sleep
Stop	Stop	FM-ST	Pre Ch
Play	Play	Intro/CT	Ok
Pause	Pause	Mute	Mute
>>I	>>I	Folder/Preset Up	Ch +
I<<	I<<	Folder/Preset	Ch -
Record	Rec		
Disc Skip	Options		
CD	1		
EQ	2		
Tuner	3		
B.Boost	4		
Tape	5		
Open-Close	Eject		
AUX	6		

https://mandos-a-distancia.es/en/Thomson/1058214-10844-replacement-remote-control-for-Thomson-CS520-55869420.html