Mandis shop

Yamaha WY92710

Original		Replacement	
	Power		Power
	Sleep	PROG SLEEP	Sleep
	CD	1	1
	iPod	2	2
	AUX	3	3
	Tuner	4	4
	USB	6	6
	Folder Down	CH –	Ch -
	Folder Up	+ CH	Ch +
	←		<<
	→		>>
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
	Menu	TOP MENU MENU	Menu

Original		Replacement	
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I<<		I<<
	Stop		Stop
	Option	SETTINGS OPT	Options
	Back	RETURN BACK	Back
	X	APP MEDIA	Media
	Display	DISPLAY INFO	Info
	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
	Mute		Mute
	<< Tuning	A	Red
	Tuning >>	B	Green
	< Preset	C	Yellow
	Memory	SEARCH TV/R	TV/R
	Preset >	D	Blue

https://mandos-a-distancia.es/en/Yamaha/1057013-24567-replacement-remote-control-for-Yamaha-WY92710-WY927100.html