Mandis shop

LG COV31606201

Original		Sustituto	
POWER	Power		Power
RGB	RGB	PROGRAM TV/ RADIO	TV/Radio /
VIDEO	Video	VIDEO 4	4
STILL	Still	STEP-FREEZE II	Pause / Step / Freeze
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
BLANK	Blank	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
RATIO	Ratio	FORMAT PICTURE	Picture / Format
	Left		Left
OK	OK	OK	OK
	Right		Right
AUTO	Auto	MEDIA DISPLAY	Display / Media
	Down		Down
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
INFO	Info	ANGLE INFO	Info / Angle
KEYSTONE	Keystone	RDS AV INPUT	AV / Input / RDS

Original		Sustituto	
ECO	Eco	LIST SMART	Smart / List

https://mandos-a-distancia.es/es/LG/1060219-24098-mando-de-sustitucion-para-LG-COV31606201.html