Mandis shop

RT160- 301

| Original | | Sustituto | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| TIMER | Timer | TIMER AV | AV |
| MONITOR | Monitor | HOME SMART | Smart |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| SELECT | Select | OK | Ok |
| CLEAR | Clear | CLEAR EXIT | Exit |
| SYSTEM | System | TOP MENU MENU | Menu |
| OK | Tracking | SETTINGS OPT | Options |

| Original | | Sustituto | |
|---|---|---|---|
| SP/LP | SP/LP | PICTURE FORMAT | Format |
| P+ | P+ | + CH | Ch + |
| P- | P- | CH − | Ch - |
| RECORD/QTR | Record | REC MODE | Rec |
| | << | | << |
| PLAY | Play | PLAY MODE | Play |
| | >> | | >> |
| INDEX | >I / Index | | >>I |
| STOP | Stop | | Stop |
| STILL | >I < / Still | ECO 3D | 3D |

https://mandisdistance.es/1656326-mandis-sustituto-para-g700-sv-2016000.htm