Mandis shop

Yamaha VDQ76100

| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| TV | TV | TV 1 | 1 |
| OPTICAL | Optical | OPT-TOOLS SETUP | Setup / OPT / |
| BLUETOOTH | Bluetooth | BLUETOOTH 9 | 9 |
| ANALOG | Analog | MEDIA DISPLAY | Display / Media |
| CLEAR VOICE | Clear Voice | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| BASS EXT | Bass Ext | LANG I/II AUDIO | Audio / Lang I/II |
| STEREO | Stereo | TITLE SOUND | Sound / Title |
| STANDARD | Standard | GOTO TEXT | Text / Goto |
| MOVIE | Movie | FORMAT PICTURE | Picture / Format |
| GAME | Game | LIST SMART | Smart / List |
| + | Subwoofer + | + CH PAGE | CH+ / Page+ |
| INFO | Info | ANGLE INFO | Info / Angle |
| + | Volume+ | + VOL | Vol + |
| DIM | Dim | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| − SUBWOOFER | Subwoofer- | CH PAGE − | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Sustituto | |
|---|---|---|---|
| − VOLUME | Volume- | VOL − | Vol - |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

https://mandisdistance.es/Yamaha/10658957-mando-sustituto-para-Yamaha-VDQ76100.htm