Mandis shop

NAVMAN001

Original		Sustituto	
	X	OK	OK
	Home	HOME MENU	Menu / Home
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
	Go	SLOW ▶	Play / Slow
	Brightness+	CH PAGE +	CH+ / Page+
	Brightness-	CH PAGE −	CH- / Page-

Original	Sustituto

https://mandisdistance.es/NAVMAN0058-506-mando-sustituto-para-NAVMAN0066-GNAV001.htm