Mandis shop

Philips 996580002887

Original		Sustituto	
	Power		Power
COAX	Coax	A	Red
OPTICAL	Optical	B	Green
AUX	Aux	C	Yellow
AUDIO IN	Audio In	D	Blue
USB	Usb	APP MEDIA	Media
	Bluetooth	HOME SMART	Smart
HDMI ARC	Hdmi Arc	SETTINGS OPT	Options
	I<		I<<
	>I		>>I
	Play	PLAY MODE	Play
	Pause		Pause
BASS +	Bass+		Up
BASS −	Bass-		Down
+	Vol+	VOL +	Vol +
−	Vol-	VOL −	Vol -
	Mute	MUTE	Mute

Original		Sustituto	
TREBLE +	Treble+	CH +	Ch +
TREBLE −	Treble-	CH −	Ch -
SOUND	Sound	SOUND DUAL	Dual
OFF SURROUND	Surround Off		Left
SURROUND ON	Surround On		Right
AUDIO SYNC −	Audio Sync-		<<
AUDIO SYNC +	Audio Sync+		>>
DIM	Dim	-/-- GUIDE	Guide
NIGHT	Night	FAV PRE-CH	Pre Ch

https://mandos-a-distancia.es/es/Philips/1055191-65628-mando-de-sustitucion-para-Philips-996580002887.html