Original		Sustituto	
	Power		Power
AUX	AUX	A	Red
TAPE 1/2	TAPE 1/2	B	Green
CD	CD	C	Yellow
TUNER	TUNER	D	Blue
INC. SURR.	INC SURR.	HOME SMART	Smart
DBB	DBB	GUIDE	Guide
DSC	DSC	FAV PRE-CH	Pre Ch
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	>I		>>I
	I<		I<<
	>>		>>
	<<		<<
	Program	PROG SLEEP	Sleep

Original	Sustituto

Original		Sustituto	
	Power		Power
AUX	AUX	A	Red
TAPE 1/2	Tape 1/2	B	Green
CD	CD	C	Yellow
TUNER	Tuner	D	Blue
INC. SURR.	INC SURR.	HOME SMART	Smart
1	1 CD Direct	1	1
CD DIRECT 2	2 CD Direct	2	2
3	3 CD Direct	3	3
DBB	DBB	-/-- GUIDE	Guide
DSC	DSC	FAV PRE-CH	Pre Ch
+	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
PAUSE	Pause		Pause
	Play	PLAY MODE	Play
	>I		>>I

Original		Sustituto	
	I<		I<<
	Stop		Stop
	>>		>>
	<<		<<
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep

Original		Sustituto	
	Power		Power
AUX	AUX	A	Red
TAPE 1/2	TAPE 1/2	B	Green
CD	CD	C	Yellow
TUNER	Tuner	D	Blue
INC. SURR.	INC SURR.	HOME SMART	Smart
DBB	DBB	GUIDE	Guide
DSC	DSC	FAV PRE-CH	Pre Ch
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
PAUSE	Pause		Pause
	Play	PLAY MODE	Play
	>I		>>I
	I<		I<<
	Stop		Stop
	>>		>>

Original		Sustituto	
	<<		<<

Original		Sustituto		Original	Sustituto
	Power		Power		
AUX	AUX	A	Red		
TAPE 1/2	TAPE 1/2	B	Green		
CD	CD	C	Yellow		
TUNER	Tuner	D	Blue		
INC. SURR.	INC SURR.	HOME SMART	Smart		
DBB	DBB	GUIDE	Guide		
DSC	DSC	FAV PRE-CH	Pre Ch		
	Vol+	VOL +	Vol +		
	Vol-	VOL −	Vol -		
MUTE	Mute	MUTE	Mute		