Mandis shop

ROTEL RR927- AMP4

Original	Sustituto	Original	Sustituto
Power	Power	>> Tape	>> / Tune+
Band	TV/ Radio /	<< Tape	<< / Tune-
A Tun	Text / Goto	Vol +	Vol +
< Tuning	Left		
Tuning >	Right		
Vol -	Vol -		
SRND Mode >	CH+ / Page+		
< SRND Mode	CH- / Page-		
CTR ECS	Picture / Format		
On Screen	Display / Media		
Delay Time >	Up		
< Delay Time	Down		
BAL CHK	Fav / Marker / PC		
Rec Tape	Rec / Rec Mode		
Stop Tape	Stop / Hold		
Pause Tape	Info / Angle		
Play Tape	Yellow / YouTube / Repeat		

https://mandis-distance.es/ROTEL/10534-553-mando-sustituto-para-ROTEL-RR927-AMP4.htm