Mandis shop

Samsung BP5900139A

Original		Sustituto	
ON	On		Power
AUTO	Auto	2	2
OFF	Off	SHIFT +	Shift + Power
MENU	Menu	MENU	Menu / Home
RETURN	Return	BACK	Back / Return
	Up		Up
	Left		Left
	Enter	OK	OK
	Right		Right
	Down		Down
V.KEY-STONE+	V.Keystone+	CH PAGE +	CH+ / Page+
BLANK	Blank	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
V.KEY-STONE-	V.Keystone-	CH PAGE -	CH- / Page-
STILL	Still	STEP-FREEZE	Pause / Step / Freeze
VIDEO	Video	4	4
COMP	Comp	1	1

Original		Sustituto	
HDMI	HDMI	0	0
S-VIDEO	S-Video	5	5
PC	PC	FAV MARKER	Fav / Marker / PC
INSTALL	Install	D.MENU	D.Menu / Top
P.SIZE	P.Size	ZOOM	Zoom / Size
P.MODE	P.Mode	PICTURE	Picture / Format

https://mandos-a-distancia.es/es/Samsung/1066751-3426-mando-de-sustitucion-para-Samsung-TM91-BP59-00139A.html