Mandis shop

Sony RMSR5

Original	Sustituto
Disc Skip	Blue / Prime Video / Random
Sleep	Sleep / Timer
Power	Power
CD Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Tuner/Band	Yellow / YouTube / Repeat
I<<	I<< / Preset-
>>I	>>I / Preset+
Deck A Play	Red / Netflix / Search
<<	<< / Tune-
>>	>> / Tune+
Deck B Play	Green / APP / Repeat
Check	Display / Media
Clear	Exit / Cancel / Clear
MD Play	Shift + Play /
Pause MD	Shift + Pause / Step / Freeze

Original	Sustituto
Stop MD	Shift + Stop /
Loop	Smart / List
Flash	Info / Angle
Function	Menu / Home
Up	Up
Vol +	Vol+
On /Off	OK
Down	Down
Vol -	Vol-

https://mandos-a-distancia.es/es/Sony/1058651-23109-mando-de-sustitucion-para-Sony-RM-SR5-147557211.html