Mandis shop

RC-393

Original		Sustituto	
COUNTER CLEAR	Counter Clear	CLEAR EXIT	Exit
DISPLAY	Display	DISPLAY INFO	Info
AUTO MONITOR	Auto Monitor	HOME SMART	Smart
REC MUTE	Rec Mute	MUTE	Mute
RECORD	Record	REC MODE	Rec
PAUSE	Pause		Pause
<<	<<	<<	<<
>>	>>	>>	>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play

Original	Sustituto

https://mandos-a-distancia.es/es/Teac/1063866-93176-mando-de-sustitucion-para-Teac-RC-393.html