Mandis shop

VibroShaper VIBROSHAPER

Original		Sustituto	
	Power		Power
	I>		Play / Slow
	I>		Pause / Step / Freeze
	Vel+ / Speed+		Up
	TPO- / Time-		Left
	TPO+ / Time+		Right
	Vel- / Speed-		Down
	M		Menu / Home
	P		Info / Angle

Original	Sustituto

https://mandos-a-distancia.es/es/VibroShaper/1066804-96439-mando-de-sustitucion-para-VibroShaper-Vibroshaper.html